INSTRUCTION MANUAL

M39-23

39-23 DERFORMANCE

M39-23B





CONTENTS	2
Safety Warnings	3
Danger Levels	3
Connection to the Electricity network	4
Use	4-5
Trasport	6
Accessories and spare parts	7
Extension cables	7
Symbols used in the Manual	8
License Plate	8
Purpose and content of the manual	9
Recipients	9
Storage of the use and maintainance manual	9
Taking the delivery of the Appliance	9
Data for Identification	9
Technical Description	10
Reasonably foreseeable misuse	10
Intended use	10
Safety	10
Handling of the Packed Equipment	11
How to unpack the appliance	12
How to Transport the appliance	13
Location of components	14
Preparation of the appliance	15
Battery charging and installation	16
Refilling of the detergent solution	17
At the end of work	18
Maintenance	19
Checking and cleaning the Velcro Plate	20
Checking and cleaning the solution tank	20
Checking and Cleaning the Motorhead	21
Troubleshooting	22
Disposal	22
EC Declaration of Conformity MI 39-23E	23
EC Declaration of Conformity MI 39-23 B	24

SAFETY WARNING





Before using the MicroImpulse for the first time, read and follow these safety warnings. Keep these safety warnings for later reference or to give to subsequent owners.

Read the machine's user manual before starting up.

The warning labels on the machine provide important information for safe use.

Always observe both the indications given in the instructions and the current safety-accident prevention regulations.

Keep the packing films out of the

reach of children. Danger of asphyxiation!

DANGER LEVELS



DANGER: Indicates an imminent danger that will result in death or serious injury.



MARNING: Indicates a likely hazardous situation that could result in death or serious injury.



CAUTION: Indicates a likely hazardous situation that could cause minor injury.



CAUTION: Indicates a probable hazardous situation that could result in property damage

CONNECTION TO THE ELECTRICITY NETWORK



DANGER:

- To reduce the risk of fire, electric shock, or injury, please read and follow all safety instructions and cautions before use. This machine is designed to be safe when used for cleaning functions as specified. In the event of damage to electrical or mechanical components, the machine must be repaired at a competent service center or by the manufacturer before use, to avoid further damage to the machine or physical injury to the user.
- Before connecting the machine to the power outlet, check that the electrical data shown on the plate correspond to those of the power supply network. The machine must be powered exclusively by alternating current and with a voltage equal to that indicated on the data plate.
- The socket for the power supply cable must be properly earthed.
- The power supply cable delivered with the machine must be used for the aforementioned appliance and not for other appliances.
- Before each use, check the connection line and power plug for damage. If the line is damaged, contact a technician immediately to restore correct operation.
- Connect the appliance only to an electrical connection installed by an electrical installer in accordance with IEC 60364-1.
- Never touch the power plug with wet hands.
- Make sure that the mains connection cable or the extension cable are not damaged by passing over them, crushing them, pulling them or the like. Protect the cable from heat and contact with oils or sharp edges.
- Regularly check that the mains connection cable is not damaged, eg by cracking or aging. If damage is detected, the cable must be replaced before using the appliance again.
- Protection against splashes of water and mechanical resistance must be guaranteed even after replacing any joints in the mains connection cable or extension cable.
- Do not clean the appliance with a flexible hose or a high-pressure water jet (risk of short
- circuit or other electrical faults).

ATTENTION:

- The switch-on transient causes a temporary voltage drop.
- Under unfavorable network conditions other equipment can be damaged.
- Such damage is expected if the mains impedance is less than 0.15Ω .

USE



DANGER:

- Use with damaged cord or plug is prohibited. To disconnect from the electrical outlet, grasp the plug, not the cord. Do not handle the plug or the machine with wet hands. Disable all controls before unplugging from the electrical outlet.
- Do not pull the machine or carry it by the cord, do not use the cord as a handle, do not close a door on the cord, or pull the cord around sharp edges or corners. Do not run the machine over the cable. Keep the cord away from heated surfaces.
- Be extra careful when cleaning on stairs.

- The machine must not be used or kept outdoors in humid conditions or directly exposed to rain.
- The storage temperature must be between -25 ° C and + 55 ° C.
- Conditions of use: ambient temperature between 0 ° C and 40 ° C with relative humidity between 30 and 95%. The machine has been developed for dry cleaning only and must not be used or stored outdoors in conditions humidity.
- Before use, make sure that the machine and work equipment are in perfect condition and safe operation, and in particular check the extension cable. If the condition is not intact, immediately disconnect the power plug from the mains socket, the machine must not be used.
- If the machine is used in hazardous environments (for example petrol stations) the relevant safety regulations must be observed. It is forbidden to use the machine in potentially explosive atmospheres.
- Certain substances can form explosive vapors and mixtures together with the intake air.

WARNING:

- Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts.
- Do not approach the machine with clothing that can get caught, AVOID the use of scarves, shawls, foulards and loose clothing
- The use of the machine is allowed to children over the age of 8 and to persons with reduced physical, sensory or mental abilities or without experience and knowledge as long as they are supervised or have received instructions concerning the safe use of the appliance and understand the associated risks.
- Children must be supervised to ensure that they do not play with the appliance.
- Children are prohibited from carrying out unsupervised cleaning and maintenance by the user.
- This machine is intended for indoor use only.
- Do not leave the machine unattended when it is connected to the mains. Unplug the power plug from the outlet when not in use and before maintenance.
- In the event of low temperatures, the machine must not be used outdoors.
- Do not use the machine on surfaces with an inclination greater than that indicated by
- registration plate.
- Always make sure that the worktops, slabs and ramps are able to support the weight of the machine.
- The machine is not suitable for cleaning uneven or uneven floors. Do not use the machine on
- In case of danger, act promptly to remove the plug in the power cable from the mains socket.

CAUTION:

- Avoid working on pieces of rope, wire, cables: these could get caught in the brush
- and create friction.
- The machine is suitable for cleaning carpet or textile floors, if used with right accessories.
- The polishing operations must be carried out in areas forbidden to the passage of unauthorized persons. Mark the work areas with special warning signs.
- Caution, do not allow the power cord to come into contact with the rotating plate.

- The machine does not cause harmful vibrations.
- Do not place liquid containers on the machine.
- In case of fire, use powder extinguishers. Do not use water.
- Do not allow the pad support plate to work with the machine stopped to avoid damage to the floor.
- The machine must only be stored indoors.
- Always use the machine in accordance with its intended use, taking into account local conditions and paying attention during work to the presence of third parties, especially children.
- Never leave the machine unattended until you turn it off and unplug it
- power supply from the wall socket.
- To avoid unauthorized use of the machine, the power supply must be interrupted, turn off the machine and disconnect the power cord from the socket.
- The machine left unattended must be protected from unintentional movements.

TRANSPORT



WARNING:

- Before transport, lock the handlebar from any movement.
- Do not overturn the machine if there is liquid in the detergent solution tank.
- During transport of the machine, the engine must be switched off, and also that the machine is in a stable and safe position.
- Lift or move MicroImpulse using the handles on the front and back.

MAINTENANCE



DANGER:

- Before cleaning and maintaining the machine and before replacing any
- components, turn off the machine and disconnect the power plug from the wall outlet.
- Repairs must only be carried out by authorized service centers or by personnel experienced in this sector, who are familiar with all the safety regulations in force on the subject.
- Observe the safety check in accordance with local regulations for commercial appliances.
- Always work on the machine wearing suitable protective gloves.



CAUTION:

- When anomalies are found in the operation of the machine, make sure that they are not due to the lack of routine maintenance. Otherwise, request the intervention of the authorized service center.
- In case of replacement of parts, request the ORIGINAL spare parts from a dealer and / or Authorized Reseller.
- Restore all electrical connections after any maintenance intervention.
- Have the machine checked by an authorized service center every year.
- Arrange for the disposal of consumables in strict compliance with the laws in force. When, after years of valuable work, your machine must be put to rest, arrange for the appropriate disposal of the materials it contains, taking into account that the machine was built with the use of fully recyclable materials.
- If the power cable is damaged, stop the machine, if you are working, remove the plug

from the power supply and have the cable replaced immediately by an authorized service center.

Use only discs supplied with the machine or those specified in the instruction manual. The use of other discs can compromise security.

ACCESSORIES AND SPARE PARTS



CAUTION:

Use only accessories and spare parts authorized by the manufacturer. Original accessories and spare parts guarantee that the device can be used safely and without malfunctions

EXTENSION CABLES



CAUTION:

CABLE LENGHT	CABLE SECTION		
CABLE LENGIT	<16A	<25A	
Untill 20mt	1.5mm ²	2.5mm ²	
From 20mt to 50mt	2.5mm ²	4.0mm ²	

Use as extension cables only the materials explicitly indicated by the manufacturer (contact authorized dealer) or models of higher quality. When using an extension cable, observe the minimum section of the same

The descriptions contained in this publication are not intended to be binding. The company therefore reserves the right to make any changes to organs, details, supplies of accessories at any time, which it deems convenient for an improvement or for any constructive or commercial need. Even partial reproduction of the texts and drawings contained in this publication is prohibited by law.

The company reserves the right to make technical and / or equipment changes. The images are intended for reference only and are not binding in terms of design and equipment.

SYMBOLS USED IN THE MANUAL



Open book symbol with i:

Indicates that the instructions for use must be consulted



| Open book symbol:

Instructs the operator to read the manual before using the appliance.

Indoor place sympol:



Procedures preceded by the following symbol must and must be carried out strictly in a covered and dry place



Warning symbol:

Carefully read the sections preceded by this symbol, strictly following the indications, for the safety of the operator and the appliance.



Protective gloves symbol:

Instructs the operator to always wear protective gloves to avoid serious injuries to the hands.



Protective gloves symbol:

Instructs the operator to always wear protective gloves to avoid serious injuries to the hands, derived from corrosive substances.

TARGA MATRICOLA

La targa matricola è posizionata nella parte destra del telaio, essa sono riportate le caratteristiche generali

dell'apparecchio in particolar modo il numero di serie dell'apparecchio. Il numero di serie è un'informazione molto importante che deve essere sempre fornita congiuntamente ad ogni richiesta di assistenza o di acquisto ricambi.



TECHNICAL DATA	U/M	
Working widht	mm	390
Depth	mm	230
Rotation	rpm	2760
Nominal power	W	550
Motor Voltage	V	230
Motor frequency	Hz	50
Slope that can be overcome under full load	%	2
Tank capacity	I	9
Rear wheels diameter	mm	110
Machine widht (in use)	mm	390
Machine height (in use)	mm	1000
Motor height from the ground	mm	270
Weight of the appiance (without solution tank)	kg	30
Power cable lenght	m	15
Sound pressure level (ISO 11201) - Lpa	dB (A)	59
UncertaintyKpa	dB (A)	1.5
Hand Vibration level (ISO 5349)	m/s ²	<2.0
Vibration measurement uncertainty	m/s ²	1.3%

PURPOSE AND CONTENT OF THE MANUAL

This manual is intended to provide the customer with all the information necessary to use the device in the most appropriate, autonomous and safe way possible. It includes information regarding the technical aspect, safety, operation, shutdown of the appliance, maintenance, spare parts and scrapping. Before carrying out any operation on the device, operators and qualified technicians must carefully read the instructions contained in this manual. In case of doubts about the correct interpretation of the instructions, contact the nearest assistance center to obtain the necessary clarifications.

RECIPIENTS

The manual in question is aimed at both the operator and the technicians qualified to maintain the appliance. Operators must not carry out operations reserved for qualified technicians. RR INTERNATIONAL is not liable for damages deriving from the non-observance of this prohibition.

STORAGE OF THE USE AND MAINTENANCE MANUAL

The Use and Maintenance manual must be kept in near the device, inside the special bag, away from liquids and anything else that could compromise its legibility.

TAKING IN DELIVERY OF THE APPLIANCE

Upon taking delivery, it is essential to immediately check that you have received all the material indicated on the accompanying documents, and also that the appliance has not been damaged during transport. If so, have the shipper ascertain the extent of the damage suffered, while informing our customer management office. Only by acting in this way and in a timely manner will it be possible to have the missing material and compensation for damages.

PREMISE

Any appliance can function well and work profitably only if used correctly and maintained in full efficiency by carrying out the maintenance described in the enclosed documentation. Therefore, please read this instruction manual carefully and reread it whenever difficulties arise when using the device. In case of need, we remind you that our assistance service, organized in collaboration with our dealers, is always available for any advice or direct intervention.

DATA FOR IDENTIFICATION

For technical assistance or to request spare parts, always mention the model, version and serial number placed on the serial plate.

TECHNICAL DESCRIPTION

This appliance was built for the professional cleaning of hard and vinyl floor surfaces, to be carried out by following the instructions. **The appliance must be used only for this purpose.**

INTENSE USE - INTENDED USE

This appliance was designed and built for cleaning smooth and compact floors, in commercial, civil and industrial environments, in conditions of verified safety, by a qualified operator. The machine is suitable for cleaning carpet or textile floors, if used with specific accessories. The device is suitable for use only in closed or covered environments.

 \triangle

ATTENTION: The device is not suitable for use in the rain or under jets of water.

REASONABLY FORESEEABLE MISUSE

The incorrect use of the appliance is linked to a use by an "inexperienced" person or in domestic environments. The manufacturer has foreseen such use, implementing safety devices and ease of use, but it is up to the end user to have the competence in using a "machine". The equipment should not be used on uneven and not very compact soils, as it would increase the risk of its overturning of the vibrating head.

The MACHINE should not be used above surfaces on which there may be electrical cables or tension extensions, as the stress of the head on them could cause the DAMAGE of the cables.

SAFETY

To avoid accidents, the cooperation of the operator is essential. No accident prevention program can be effective without the full cooperation of the person directly responsible for the operation of the appliance. Most accidents that occur in a company, at work or in transfers, are caused by non-compliance with the most basic rules of prudence. A careful and prudent operator is the best guarantee against accidents and is indispensable to complete any prevention program.

The appliance has been designed according to the relevant Directives and applying the Product Standards and those relating to safety. In order to ensure the safety standards achieved by the manufacturer, the user must take care of the equipment and regularly check the good condition of the safety components or devices that may be at risk, if damaged, damaged or not functioning. The following paragraphs contain the list of control operations to maintain the safety level achieved by the manufacturer.


HANDLING OF THE PACKED APPLIANCE

The device is contained in a package, the packaging elements (polyethylene bags, staples etc.) being potential sources of danger must not remain within reach of children, incapacitated persons etc.

The total mass of the packages is 55 kg max

The dimensions of the packaging are as follows:

- A: Cm 330
- B: Cm 410
- C: Cm 1000



HOW TO UNPACK THE APPLIANCE

To remove the machine from the packaging, do the following:

Place the lower part of the external packaging in contact with the floor.


ATTENTION: Handle the packaged product with suitable lifting means compliant with legal provisions.


Remove the outer carton from the pallet.


WARNING: It is recommended to always wear protective gloves to avoid serious hand injuries.



- 1. Grab the machine from the rear trolley and front head and place it on the floor (Figure 1)
- 2. Looking at the machine from the front (Engine View) insert in the handle the Kit 1 and the Kit 2 as shown (Fig.2)
- 3. Tighten the drawbar with the right side lever and move the machine using the 2 side wheels.8 (Fig 3)







HOW TO TRANSPORT THE APPLIANCE

To transport the device, do the following:

1 Check that the plug (1) on the power cable is disconnected from the socket (2) of the power supply, otherwise disconnect it.





WARNING: It is recommended to always wear protective gloves to avoid serious hand injuries.



CAUTION: To avoid damage to the power cord, disconnect the plug from the wall outlet by pulling the plug directly instead of the cord








3 insert the side weights and tighten them using the 4 right / left knobs



COMPONENTS



2			
	Schuko socket		
3	Water lever		
4	Handle Handle		
5	Upper tank connection		
6	Lower tank connection		
7	Rudder release / lock lever		
8	Left Locking Plunger pcs.1		
9	Locking Screw pcs.1		
<mark>10</mark>	Trolley		
<mark>11</mark>	Motor 220 V		
<mark>12</mark>	Left ballast knob (2 pcs)		
<mark>13</mark>	Weights 5 Kg. left (2 x 5 Kg Performance)		
<mark>14</mark>	Left rubber shock absorbers (2 pcs)		
<mark>15</mark>	Solution tubes left/right		
<mark>16</mark>	Right rubber shock absorbers (2 pcs)		
<mark>17</mark>	Weights 5 Kg. right (2 x 5 Kg Performance)		
<mark>18</mark>	Plate with Velcro		
<mark>19</mark>	Right ballast knob (2 pcs)		
<mark>20</mark>	Electric cable 15 meters		
21	Solution tank 9 lt.		
<mark>22</mark>	Wheels left/right		
<mark>23</mark>	Battery (only for Mi 3923B – Mi3923BP)		

PREPARATION OF THE APPLIANCE FOR THE WORKING PHASE

To make the machine operational, carry out the following:

- 1. Unlock the handle using the right side lever (Fig 1)
- 2. Bring the drawbar vertically until it is tightened with the left side pistons (fig. 2 and
- 3. Lock the handle with the same side lever (fig. 1)










- 4. Insert the left/right weights and tighten them using the 4 knobs (Fig.5)
- 5. Remove the white Pre Pad before inserting a pad depending on the job to be done. (Fig.6)





- 6. Before use, adjust the rudder as desired according to your comfort level using the right side lever. Once you have found the optimal adjustment, tighten the lever to lock the handle. (Fig.7)
- 7. Press the power button and proceed with the work (Fig.8)







ATTENTION: During this operation, do not rest your foot on the appliance. **ATTENTION:** Always keep the power cable behind the operator, taking care not to work with the machine in the vicinity of the same so as not to damage it.

BATTERY CHARGING AND MOUNTING (VERSION 39-23B and 39-39BP ONLY)

Before using the machine it is advisable to charge the battery for an entire night. When fully charged the battery charger will turn off automatically.



ASSEMBLY:

Insert the battery on the rail plate positioned on the machine handle, taking care to slide it from top to bottom.(FIG 1)

When the Battery is inserted (FIG2) you can use the machine (FIG3)



FILLING OF THE DETERGENT SOLUTION TANK

Fill the solution tank only when the handle is in a vertical position by doing the following:

1. Bring the appliance to the maintenance area.

ATTENTION: The place used for this operation must comply with current environmental legislation.

2. Check that the plug (1) on the power cable is disconnected from the socket (2) of the power supply, if not, disconnect it.



with edges or tips of metal objects.

CAUTION: To avoid damage to the power cord, disconnect the plug from the wall outlet by pulling the plug directly instead of the cord.

3. Assemble the tank on the drawbar inserting it into the special couplings (Fig. 3 upper Fig. 4 lower) and tighten with the knobs.



4. Fill the tank using a hose or jug, taking care not to let water fall on the engine. (Fig. 5)

5.Hook the tank chain into the special hole located in the handle lever (Fig.6)

6.Pull the lever to release the water / detergent solution to be used on the floor (Fig.7)





7. At the end of the operations, rinse the tank with plenty of clean water.

TERM OF OPERATIONS

At the end of the work and before any type of maintenance carry out the following operations:

1. Disconnect the plug on the power cable from the socket (Fig.1) of the power supply (Fig.2).






CAUTION: To avoid damage to the power cord, disconnect the plug from the wall outlet by pulling the plug directly instead of the cord.

2. Rotate the control handlebar to a vertical position, releasing the right side lever and making the handle hook to the LEFT side pistons, tighten the handle using the right side lever.

ATTENTION: During this operation, do not rest your foot on the appliance.



3. Tilt the machine on its rear wheels and take the machine to the maintenance area and carry out all the procedures listed in the paragraph "RECOMMENDED PERIODIC MAINTENANCE INTERVENTIONS" indicated in the "AT THE END OF WORK" column. Appliance in the place used for its rest.





ATTENTION: Park the machine in a closed place, on a flat surface, in the vicinity of the machine there must be no objects that can ruin or get damaged in contact with the machine itself.

MAINTENANCE

TYPE OF MAINTENANCE	AT THE END OF WORKING DAY	WEEKLY	ANNUAL	CARRIAGE
Check and clean the velcro plate	Х		X	X
Checking and cleaning the solution tank	X	X	X	X
Piston lubrication			Х	
Control and internal cleaning of the SCRUBBING head		Х	Х	

SAFETY CONTROL OF COMPONENTS

TYPE OF MAINTENANCE	BEGINNING OF THE WORK	MONTHLY	ANNUAL
ON/OFF button integrity check	X		
Check the condition of the Schucko cable and plug	X	X	Х
Control of the presence of the CE label			Х
Control integrity coverage of electric motor head	X	X	Х

CHECKING AND CLEANING THE VELCRO PLATE

- Lift the machine and place it horizontally on the floor
- clean the plate with a soft brush and neutral detergent
- Rinse with water
- dab with a microfiber or cotton cloth to dry



Tank check and cleaning

CLEANING THE SOLUTION TANK

Thorough cleaning of the solution tank ensures better floor cleaning.

To clean the solution tank carry out the following:

Bring the appliance to the maintenance area.






ATTENTION: The place used for this operation must comply with current environmental legislation.

Check that the solution tank is empty, if not, empty it using the right lever on the rudder.

Fill the tank with warm water and neutral detergent empty the tank using the right lever on the tiller.

Rinse with hot water only (Max 45°)

If you want to release the tank by unscrewing the 2 knobs on the back of the handle, remember to remove the water distribution pipe and insert it into the hole on the base.



Checking and cleaning of the scrubbing head

At the end of the work and before any type of maintenance carry out the following operations:

1. Disconnect the plug on the power cable from the socket (Fig.1) of the power supply (Fig.2).





CAUTION: To avoid damage to the power cord, disconnect the plug from the wall outlet by pulling the plug directly instead of the cord.

2. Rotate the control handlebar to a vertical position, releasing the right side lever and making the handle hook to the Left side pistons, tighten the handle using the right side lever.



3. Tilt the machine on its rear wheels and rest the handle on the floor



- 4. Unscrew the 4 pins located on the end of the plate, remove the plate.
- 5. Clean inside with a damp cloth
- 6. Check the integrity of the bearing
- 7. Reposition the plate on the motor
- 8. Mount the 4 pins placed on the end of the plate by tightening them crosswise.



TROUBLESHOOTING

This chapter lists the most recurring problems related to the use of the device. If you are unable to solve the problems with the following information, please contact the nearest service center.

TROUBLE	POSSIBILE CAUSE	SOLUTIONS
	The extension cable is not connected to the power supply.	Check that the plug on the extension cable is inserted into the mains socket power supply
	The extension cable is not connected to the power cable of the appliance.	Check that the plug in the power cord of the appliance is inserted into the socket on the extension cable.
THE APPLIANCE DOES NOT TURN ON	The electrical specifications of the appliance correspond with the electrical specifications of the power supply network.	Check that the electric specifications of the device correspond with the electric specifications of the power supply network, check the technical data present on the serial number plate.
	Damaged extension cable.	Check that the extension cable is not damaged, if it is damaged replace it.
	Motor overheating	Stop the machine immediately and let the engine cool down, then call a nearest assistance Center.
NOT ENOUGH DETERGENT SOLUTION ON THE PLATE	Quantity of detergent solution unsuitable for the job to be done	Check that intake pipes solution on the plate behind the MI logo placed on the engine are not crushed.

DISPOSAL

Proceed to Scrapping the appliance at an authorized emolition center or collection center. Before scrapping the device, it is necessary to remove and separate the following materials and send them to separate collections in compliance with the current environmental hygiene legislation:

- Aluminum plate
- Electric ed electronic parts*
- Plastic parts
- Metal parts



(*) In particular, for the scrapping of electrical and electronic parts, contact the distributor.



DICHIARAZIONE DI CONFORMITÀ CE EC DECLARAT/ON OF CONFORMITY



IL FABBRICANTE/ THE MANUFACTURER

RR International s.r.l. Via Le Lamie N°9 70015 NOCI (BA) Italy

Dichiara sotto la propria esclusiva responsabilità che il macchinario: Declare entirely under our own responsibility that the product:

Denominazione/Description Nr di seriel/Sertal Nr. Anno di costruzione/Tear

MACCHINA PER TRATTAMENTO PAVIMENTI da/from 18001 a/to 18999 da/from B19001 a/to B19999 2023

Modello/Modal:

MI-3923E MI-4630E

E' conforme a quanto previsto dalle Direttive: Comply with the requirements of the following Directives:

- 2006/42/CE: Direttiva Macchine, pubblicazione gazzetta ufficiale europea 157 del 95/3005.
- · 2006/42/CE: Mackinery Directive
- 2014/35/UE: Direttiva bassa tensione, puestazione pazzeta unicare europea so der 29/32/14.
- 2014/35/UE: Low Voltage Directive.
- 2014/30/UE: Direttiva compatibilità elettromagnetica, publicazione gazzeta ufficiale europea 85 del
- 2014/30/UE: Electromagnetic Compatibility Directive.

L'oggetto della dichiarazione di cui sopra è conforme alla pertinente normativa di amionizzazione dell'Unione, di cui:

The subject matter of the abovementioned declaration shall comply with the relevant Union harmonisation legislation, referred to in:

EN12100:2010: EN60335-1:2010: EN60335-2-72:2021

Dichiara inoltre che sui beni sopra descritti è stata apposta la marcatura CE e la presente dichiarazione di conformità è rilasciata sotto la responsabilità esclusiva del fabbricante It also states that the goods described above have been affixed with the CE marking and this declaration of conformity is issued under the sole responsibility of the manufacturer

La persona autorizzata a costituire il fascicolo tecnico: The person authorized to compile the technical file:

MR Roberto La Torre Via Le Lamie N°9 70015 NOCI (BA) haly

RRINTERNATIONAL S.R.L. Elegale rappr sentante

Lingui Pycongolystative Rubjenytti Tarie



DICHIARAZIONE DI CONFORMITÀ CE EC DECLARAT/ON OF CONFORMITY



IL FABBRICANTE/ THE MANUFACTURER.

RR International s.r.l. Via Le Lamie N°9 70015 NOCI (BA) Italy

Dichiara sotto la propria esclusiva responsabilità che il macchinario: Declare entirely under our own responsibility that the product:

Denominazione/Description Nr di serie/Serial Nr. Anno di costruzione/Year

MACCHINA PER TRATTAMENTO PAVIMENTI da/from 18001 ato 18999 da/from 819001 ato 819999 2023

Modello/Model:

MI-3923B MI-4630B

E' conforme a quanto previsto dalle Direttive: Comply with the requirements of the following Directives:

- 2006/42/CE: Direttiva Macchine, putotoatore gazzeta ufficiale europea 157 del 96/2006.
- 2006/42/CE: Machinery Directive
- 2014/30/UE: Direttiva compatibilità elettromagnetica, pubbicazione gazzeta ufficiale europea 60 del 20/3/2014
- 2014/30/UE: Electromagnetic Compatibility Directive.

L'oggetto della dichiarazione di cui sopra è conforme alla pertinente normativa di armonizzazione dell'Unione, di cui:

The subject matter of the abovementioned declaration shall comply with the relevant Union harmonization legizlation, referred to in:

EN12100:2010; EN60335-1:2010; EN60335-2-72:2021

Dichiara inoltre che sui beni sopra descritti è stata apposta la marcatura CE e la presente dichiarazione di conformità è rilasciata sotto la responsabilità esclusiva del fabbricante It also status that the goods described above have been affixed with the CE marking and this declaration of conformity is issued under the sole responsibility of the manufacturer

La persona autorizzata a costituire il fascicolo tecnico: The person authorized to compile the technical flie:

MR Roberto La Torre Via Le Lamie Nº9 70015 NOCI (BA) Baly

RR INTERNATIONAL S.R.L. Il legale rappr sentante

Lagari (yayyayiyi tatisa