



Nitro Daily Maintenance



1



Drain the dirty water from the recovery tank

2



Rinse out the water tank

3



Lift the lid and check the waste filter box

4



If waste is present, remove, empty and clean

5



Wipe sensors, lasers and cameras

6



Check the correct discs are being used on your machine

7



Check the squeegee sits flat on the floor

8



Adjust or replace the blade if it's worn